





SINGLE PHASE WIRING

EXTERNAL CONNECTION 110v / 230v 1 PHASE



Clockwise from the non-cable end *

*To reverse rotation interchange BROWN lead with BLUE I

IMPORTANT

UNIT MUST NOT BE RUN WITHOUT A BELT OR SOME OTHER FORM OF HEAT TRANSFER SYSTEM. HEAT GENERATED BY THE MOTOR MUST BE DISSIPATED OTHERWISE IRREVERSIBLE DAMAGE MAY OCCUR TO TRANSMISSION SYSTEM.